



RING MOD: SHIFT+**2**
 FILTER CUT: SHIFT+PATTERN+**2**
 FILTER RES: SHIFT+PATTERN+PLAY **2**

PITCH SINGLE VOICE: **3** SET DECAY OF SINGLE VOICE: **4**
 PITCH ALL: SHIFT+**3** ACTIVATE DELAY: SHIFT+**4** (>50%)
 CHAIN PATTERNS: HOLD PATT + UP TO 16 PADS
 TOGGLE GLOBAL PITCH/DECAY ON/OFF: SHIFT+PLAY

SET DELAY TIME: SHIFT+PLAY+**4**
 SET DELAY PITCH DECAY: SHIFT+PLAY+**3**
 SET PUMP: SHIFT+**5**

MIDI IMPLEMENTATION

MASTER VOLUME: CC7

FILTER ON/OFF: CC43

FILTER CUTOFF: CC44

FILTER RESONANCE: CC45

RINGMOD ON/OFF: CC46

RINGMOD X: CC 47

VOLUME VOICE 1: CC10

VOLUME VOICE 2: CC11

VOLUME VOICE 3: CC12

VOLUME VOICE 4: CC13

VOLUME VOICE 5: CC14

VOLUME VOICE 6: CC15

VOLUME VOICE 7: CC16

VOLUME VOICE 8: CC17

DECAY VOICE 1: CC20

DECAY VOICE 2: CC21

DECAY VOICE 3: CC22

DECAY VOICE 4: CC23

DECAY VOICE 5: CC24

DECAY VOICE 6: CC25

DECAY VOICE 7: CC26

DECAY VOICE 8: CC27

PITCH VOICE 1: CC30

PITCH VOICE 2: CC31

PITCH VOICE 3: CC32

PITCH VOICE 4: CC33

PITCH VOICE 5: CC34

PITCH VOICE 6: CC35

PITCH VOICE 7: CC36

PITCH VOICE 8: CC37

STUTTER ON/OFF: CC40

STUTTER RATE: CC41

STUTTER PITCH: CC42